
# T R Í M M COPENHAGEN

## COCOON HANG CHAIR



## COCOON HANG CHAIR

Cover material: Sunbrella Plus®

Frame material: Powdercoated stainless steel

Colors: Beige, Taupe, Grey, Graphite

Weight: 11,5 kg

**Dimensions:** 0: 112 × D: 67 × H: 165 cm

Max Load: Depends on the mounting, advise your local hardware store.

#### Features:

· Water- and stain repellent

Algae resistant

· UV- and fade resistant

Breathable comfort

Produced in the EU

· Removable cover









### General cleaning:


- Remove the cover from the frame
- · Brush off any loose dirt.
- · Hose down fabric thoroughly. Water should be cold to lukewarm and never more than 100°F/38°C.
- Prepare a cleaning solution of water and mild soap (No detergents).
- Use a soft bristle brush to clean. Allow cleaning solution to soak into the fabric.
- Be sure to rinse thoroughly to remove all soap residue.
- Put the cover back on the frame and allow the fabric to air dry. Never apply heat.

## Deep or stubborn cleaning:


If stubborn stains or mildew persist, you can use a diluted chlorine bleach/soap mixture for spot cleaning. Protect the area around the Sunbrella fabric when using a bleach solution - bleach may discolor non-Sunbrella fabrics. Always rinse Sunbrella thoroughly in order to completely remove bleach.

HAND WASH: Mix 100 ml chlorine bleach with 50 ml of mild soap and one 4 l of water. Clean with a soft bristle brush. Allow mixture to soak into the fabric for up to 15 minutes. Rinse thoroughly until all soap residue is removed. Allow the furniture to air dry. Repeat if necessary.


## HOW TO TIE THE ROPE CORRECTLY




Step 1. Put the rope in front of the steel frame




Step 2. Make a loop.




Step 3. Put the end of the rope around the frame and up into the loop



Step 4. Then take the end and put it behind the rope and down into the loop again.



Step 5. Tighten the knot



Step 6. Your new Cocoon Hang Chair is ready for use.

NOTE: When using together with the Cocoon Stand, shorten the rope to adjust the hanging height of the chair.

